Your Global Automation Partner



# CMVT Vibration/Temperature Sensors for Condition Monitoring







Products are linked with further information.



## Condition Monitoring through Vibration Monitoring

Every machine generates vibrations even when new. However, the vibration states can change due to various factors, such as imbalances, loose parts, misalignment of shafts or contamination of rotor blades.



Imbalance



Loosening

-

Misalignment



Contamination

ISO 10816-3 specifies precise limit values for the effective vibration velocity of industrial rotary machines. These limit values are used to assess the condition of the machine. They indicate whether the machine is operating in a good condition similar to new, whether short-term operation can still be tolerated despite increased vibrations but rapid maintenance is recommended, or whether the vibrations are so severe that machine damage is to be expected.

The CMVT sensor analyzes the vibration behavior of machines and detects critical machine conditions. On the one hand, the CMVT supports the planning of maintenance intervals in the sense that maintenance is carried out only when it is really necessary; on the other hand, the sensor improves the safety of machine operation by warning in good time when a critical vibration condition is imminent.

In addition to an increase in vibration, machine faults frequently cause rising temperatures due to greater friction. For this reason, the CMVT records the temperature in addition to the vibration, which serves to further record the condition of the machine. All these considerations increase the availability and effectiveness of the machine and ensure that imminent faults are detected and rectified in good time, thus preventing expensive damage and unplanned machine downtimes from occurring in the first place.





Maintenance-free operation Robust and sealed housings with protection class IP68/IP69K and a high shock resistance of 200 g as well as a wide temperature range of -40 °C...+85 °C allow maintenance-free operation even in demanding environments.



Measurement over three axes Thanks to the 3D measuring cell, the CMVT records the vibration over three axes, offering a choice between effective vibration velocity (acceleration) and peak-to-peak value. The sensor also detects rising temperatures, which can indicate increased machine wear, for example.





Applications with recurring vibrations

If the vibration increases during recurring processes, this can indicate damaged or worn tools. The CMVT offers the possibility to parametrize alarm or warning limits as required and to activate simple switching outputs when these limits are exceeded.

### Fan with increasing imbalance



The smallest changes in vibration behavior or a steady increase in vibration velocity can be output as a process value via IO-Link and transferred to the controller for further analysis.

Solution without PLC integration



Simple retrofit of existing systems without PLC integration via switching outputs on a tower light



Simple integration via IO-Link The IO-Link protocol guarantees simple data transmission and generates additional information, such as sensor identification or the number of operating hours. In addition, the sensors can be parametrized so that switching outputs are activated as a warning or alarm when threshold values are exceeded.





Simple commissioning of the sensor using standardized IO-Link protocol



#### Vibration monitor

The free web-based vibration monitor is the best solution for enabling easy visualization and analysis of the vibration data. All Turck IO-Link masters have the vibration monitor implemented directly as a web server.



### Types and Features

#### Vibration monitor

The vibration monitor is a web-based tool implemented directly as a web server for all Turck IO-Link masters. The vibration data recorded over three axes can be displayed very easily in the web browser and made available for further analysis via data export. Setting individual vibration velocity threshold values via the vibration monitor is also particularly easy. PNP/NPN outputs are set to activate a warning or alarm when the threshold values are exceeded. In the event that no Turck IO-Link master is used, the web demo and configuration tool represents the best solution. This free tool also allows web-based access to the full performance spectrum of the vibration monitor thanks to a simple connection from the PC via the USB-2-IOL-0002 parameterization device to the CMVT vibration sensor.

- Easy analysis of vibration and temperature
- Simple parameterization process, e.g. for setting the threshold values of switching outputs, for activating warnings or alarms

10.4 90	KODD Configurator	
	Read (Hris Units 2000 CRV Eq. 1 Constant Mentalization Speciality	
	Parameter The serves a visible and temps three server's end temps in OR22 housing with Out-in indiana, 12226 and a MIC 4pm contexts. Vot Struct. 2007 (Server South 2) 2011 Name House Can KD	
	Depression Vibration meetitor	
	C tot/fee	
	Observation U	
	Brown dds	
	Powerday *	
	Virulin metion *	
	Survey of the second se	
	Advert	
	Contractions 4	
	1	

Example visualization of vibration across three detection axes on a fan

ID	Type designation	Description
100016543	CMVT-QR20-IOLX3-H1141	CMVT sensor with M12 male connector
100029966	CMVT-QR20-IOLX3-0.3-RS4	CMVT sensor with cable outlet and M12 male connector

Ĵ

Products are linked with further information.

